



BALD BUDDY™

Rechargeable C-type plug • Wet/Dry

Model – SKU4000 Bald Buddy

Contact: info@thecutbuddy.com

©2022 The Cut Buddy

THECUTBUDDY.COM



BALD BUDDY™

ERGONOMIC • WET & DRY SHAVER



**THE CUT
BUDDY**

USER MANUAL

Model – SKU4000

BALD BUDDY™

ERGONOMIC • WET & DRY SHAVER

STAINLESS FOIL
Dual precision foil
with slots to trap
stubble and
protect skin

5-BLADE ROTARY HEAD
3D contouring shaving
system adjusts to your skin

❗ If one of these CB circular caps fall out, do not panic! Your shaver works the exact same without them.

The Bald Buddy shaver allows you to shave every inch of your head, even those hard-to-reach areas you can't see (the back of your head) with ease! The patented ergonomic grip provides control for a smooth and enjoyable shaving experience. Some other Bald Buddy features include:

ERGONOMIC HANDLE
Designed for comfort and
and easy handling

BATTERY INDICATOR
Know when your battery
power is getting low


**SOFT-TOUCH
ON/OFF SWITCH**
Designed for your hand with
a convenient power button

**C-TYPE
PLUG/USB**
Charge the shaver
any place, any time

FOR BEST SHAVING EXPERIENCE

While The Bald Buddy is designed for both wet and dry shaving, understand that **NOT ALL PEOPLE SHOULD DRY SHAVE!**

*If you are interested in dry shaving,
please see our suggestions:*



STEP UP YOUR GAME
Try our Shaving Bundle
with 3 Step Ingrown
Hair & Irritation Defense

	DRY SHAVING (NO WATER OR SHAVING CREAM) CAN WORK WELL FOR YOU IF...	WET SHAVING (WITH WATER OR SHAVING CREAM) IS RECOMMENDED FOR YOU IF...
Hair Type	Thinner hair	Thick, curly, coarse, tough
Head Shape	Rounder head shape	Different contours
Ingrown Hairs	You don't suffer from ingrown hairs	Frequent ingrown hairs
Skin	You have hydrated skin	Dryer skin
Frequency	You shave daily	You shave every 2 days or less
Rotary Shaving Experience	You usually only need 1 pass of shaver to finish the job	You usually need 2 passes of shaver. Small circular patterns as you shave

IMPORTANT:

- Do not use on thickened head hair (ex: eyebrows); only recommended for use on clean, lotion-free skin.
- It is highly recommended to exfoliate your skin before shaving.
- Do not disassemble unit to avoid breaking seals and allowing moisture to enter the shaver.
- Use this shaver only for the purposes described in this manual.
- Do not use unit in the bathtub or pool. The unit's waterproofing is suitable only for shower use, rinsing, and cleaning of unit.
- For hygienic reasons, the blades should only be used by one person.

If more than one person is using shaver, **purchasing extra blades is highly recommended.**

- Disposable blade replacement is **recommended every 3 months.**
- To prevent damage or injuries when using the shaver, **use the unit away from your eyebrows, eye lashes, clothes, threads, and all loose objects.**
- Do not use unit if you see any damage to the shaver head or if it appears to be broken. This may cause injury. Always order a new blade if you drop or damage the shaver head.
- Do not use the appliance on irritated skin or skin with varicose veins, rashes, spots, moles or wounds without consulting a doctor first.

HOW TO USE YOUR BALD BUDDY™



USE ON HEAD & BODY

- Remove protective cap.
- Press the on/off switch to turn on.
- Place the shaving head on desired area and shave in a short circular motion.
- Keep all heads touching the skin with equal light pressure. For tougher spots (back left or right side of head), concentrate only 1 or 2 blades in small circular patterns.
- Shave as fast or slow as you desire.
- Rinse shaver after every full pass of head or body area for best performance.



USE ON FACE

- Remove protective cap.
- Press the on/off switch to turn on.
- Place the shaver at a right angle to the skin so all heads are touching skin with equal pressure.
- Puff up skin (making cheeks flat) to give shaver easier glide surface.
- Use short circular strokes and apply light pressure to shave the face.
- Rinse shaver after every full pass of face area for best performance.

- Trim down longer hairs before using on facial hair.
- Do not use very scalding hot water to wash heads. You can also deep clean in a cup of Rotary and Shaver cleaner solution. Just turn on shaver and dip only the shaver heads in a small cup filled with the solution, or, if you just want to just quickly rinse the shaver, you can use just water.
- It is recommended to use rotary and foil shaver cleaner to disinfect blades properly. These cleaners can be found on Amazon.
- We recommend to rinsing shaver heads after each use to clean away stubble.



CHARGING ⚡

- Fully charge the product before using the appliance for the first time, or if it has not been used in quite a while. (2-hour charging time)
- If fully charged, you can use the appliance for ~75 minutes.
- Insert the C-plug into the waterproof charging port of the shaver and the USB end to your charging source (such as a USB device or using the USB wall adaptor) and the light ⚡ will come on to indicate that the appliance is charging.
- Charge the appliance for 2 hours until the battery indicator light turns off. Once the battery indicator light turns off, the unit is fully charged.
- When the unit is fully charged, the battery 🔋 and light ⚡ symbols are on all the time.
- When a customer charges the unit with the wrong voltage (over 5V), three indicators will quickly flash for 10 seconds. Unit will not be charged because of battery protection.

TRAVEL LOCK 🔒

To switch to off-state, push the on/off switch for 3 seconds until light flashes 🔒 2 times and goes into the locked state. If you try to turn on, the light will just flash indicating the unit is locked. To unlock: same instructions, push and hold down the on/off switch for 3 seconds.

Note: Only extended USB-C type adaptors will charge shaver. Normal USB-C (android, phone etc.) will not charge shaver.

The unit can usually be used right out of the box because it comes partially-charged. It takes 2 hours to fully charge the appliance. Each full charge gives you approximately 75 minutes of shaving time. If it takes you 5 minutes every time to shave, then you should get about 15 shaves from a full charge.

It is recommended to let the unit battery fully drain before recharging as this will extend battery life of the shaver. If shaver battery life is getting low while using the unit, you can plug it in to finish shaving.

